

NOTICE: Motor Performance Enhancements With Latest Firmware

This MDR's firmware was updated to the latest version in order to support the new DM2X motor and provide improved motor speed and torque performance for our existing motors. The new output torque levels are higher for each torque setting, so each motor will now have more torque to turn very stiff lenses.

However, if you plan to use this MDR with a DM1 motor in the Focus port, make sure to keep the torque setting on either **Low or **Mid**.** With a DM1 controlled by this new firmware, the **Mid** torque setting provides the same amount of torque as previous firmware did on the **High** setting. If the DM1 will be in Zoom or Iris, you can use any torque setting.

Due to the higher torque limits for each setting, repeated stalling of the DM1 motor in the Focus port on **High** torque can cause the DM1 motor to burn out prematurely.

Your existing DM2, DM1X, DM4, or DM4X motors can be used without any changes.

Please contact us at techsupport@prestoncinema.com or (310) 453-1852 with any questions or concerns.